

SET UP INSTRUCTIONS



PLACE WALL MOUNT ON DESIRED LOCATION ON WALL AND MARK HOLES FOR SCREWS. (MAKE SURE BRACKET IS LEVEL)



DRILL HOLES FOR WALL ANCHORS USING 5/16" DRILL BIT



INSERT WALL ANCHORS INTO HOLES ON WALL



SECURE MOUNTING BRACKET TO WALL WITH SCREWS



HOOK SHADOW MOUNT ON BACKSIDE OF PRINT ONTO WALL BRACKET TO COMPLETE INSTALLATION