


# 18" Tabletop Economy Retractor

## Product Parts

- 1 - Base
- 2 - Banner Rail
- 3 - Shock Corded Pole



Note: Graphic is pre-installed at factory



## Display Set-Up

### Step 1

Flip the Base (1) upside down and rotate the foot to sit perpendicular to the Base.



### Step 2

Insert the Shock Corded Pole (3) into the hole in the center of the Base (1) until it is fully seated.



### Step 3

Facing the back of the Base (1), extend the banner upward towards the top of the pole.



Insert the hook on the top of the Shock Corded Pole (3) into the groove on the Banner Rail (2) in the center where the arrow sticker is located.



## Storage & Care

Place all product parts into Carry Case and store in a cool dry location. To clean non-graphic hardware, wipe with a damp cloth.