


Prize Putt

Product Parts

- 1 - Carry Case
(sold separately)
- 2 - Putter
- 3 - Balls (x3)
- 4 - Turf
- 5 - Left Side
- 6 - Right Side
- 7 - Graphic Decals
- 8 - Graphic Inserts
- 9 - Bottom Supports (x3)



Graphics Install

Step 1


Remove all of the parts from the box and set them, along with your graphics, on a flat, clean surface.

Step 2

Remove backing from Graphic Decal A. Apply Graphic Decal A to designated area on Prize Putt as shown in Example A. Repeat for Graphic Decal B and C.

Step 3

Install Graphic Inserts D and E into designated slot on Prize Putt as shown in Example A. Do not remove backing from Graphic Inserts D and E.






Example A

Hardware Assembly

Step 4

Assemble the Bottom Supports (9) as illustrated below. Connect the larger pieces together first, followed by the smaller support. Example B shows Bottom Supports (9) fully assembled.





Example B

Hardware Assembly Continued

Step 4

Align tabs of assembled Bottom Support (9) with slots on underside of Left Side (5). Repeat this for the Right Side (6). The Left Side and Right Side will connect to each other with the hook and loop pre-installed along edge of each side.



Step 5

Attach Turf (4) to Right Side (6) with hook and loop pre-installed along bottom of Turf (4) and bottom of Right Side (6).



Storage

Place all product parts into optional Carry Case (1). Insert Left Side (5) rounded corner first into largest opening. Insert Right Side (6) into smaller opening with rounded corner first. Putter (2), Balls, (3) Turf (4) and Bottom Supports (9) will fit in either opening.



Care

Clean hardware with damp cloth and wipe dry.
Clean graphics with damp cloth and wipe dry.