
Product Parts

1 - Weight (x4)





Product Set-Up

Step 1


Remove Weight (1) from the box and place near the tent you plan to use it with.

Step 2

Unzip the top of each side. Fill sand into canvas bag. Repeat for each bag.

Step 3 -


Connect top and bottom buckles and tighten straps as necessary.



Storage

Place all Weights into box and store in a cool, dry location.

Step 4 -



Care

To clean, wipe with damp cloth.

Warranty Information: All products are designed to provide the user with a cost-effective and durable product. Standard warranty is a 'one year parts and labor' warranty which warrants product against defects in material and workmanship. It does not cover damage due to accidents, abuse, or normal wear and tear. Products found to be defective will be replaced or repaired at factory's discretion.